

Programming Instructions

TRLK-190107

Rite-Hite Dok Commander Rev-C

1. Power the LED Controller and have the Power switch in the off Position.
2. Remove the A/C signal converter Premium.
3. Ensure that no external wires are attached to the LED Controller ports.
4. Attach a small jumper wire between **Signal GND** and **Signal Close**.
5. Attach a small jumper wire between **Signal Close** and **Signal Aux**. These should be the only 2 wires installed.
6. Hold the Mode button down and, while keeping it held down, set the Power Switch to the ON position. Let go of the Mode button. The amber status LED will rapidly blink and then turn off.
7. Set the Power Switch to the OFF position.
8. Remove the jumper wires.
9. Reattach the A/C signal converter Premium.
10. You may now wire the controller as shown in the provided schematic.