



# WIRING SCHEMATIC FOR CONNECTING DOOR SAFETY KIT LIGHTING TO: **Cornell**

- Ensure that the A/C Signal Converter is attached. It's DIP switches should be set to **OPEN → AC** , **CLOSE → AC**, **AUX → DC**

